

USER MANUAL


Single Phase Hybrid Inverter

DGH02-P1M6K-EU

DGH02-P1M8K-EU

DGH02-P1M10K-EU

DGH02-P1M12K-EU



About This Manual

The manual mainly describes the product information, guidelines for installation, operation and maintenance. The manual cannot include complete information about the photovoltaic (PV) system.

How to Use This Manual

Read the manual and other related documents before performing any operation on the inverter. Documents must be stored carefully and be available at all times.

Contents may be periodically updated or revised due to product development. The information in this manual is subject to change without notice.

Contents Preface

1. Safety Introduction	3
2. Product introductions	4
2.1 Product Size	4
2.2 Product Features	7
2.3 Basic System Architecture	7
3. Installation	8
3.1 Parts list	8
3.2 Mounting instructions	8
3.3 Battery connection	10
3.4 Grid connection and backup load connection	12
3.5 PV Connection	13
3.6 CT Connection	14
3.7 Earth Connection (mandatory)	15
3.8 WIFI Connection	15
3.9 Wiring system for inverter	16
3.10 Typical application diagram of diesel generatoy	17
3.11 Single phase parallel connection diagram	18
3.12 Three phase Parallel inverter	19
4. OPERATION	20
4.1 Power ON/OFF	20
4.2 Operation and Display Panel	20
5. LCD Display Icons	21
5.1 Main Screen	21
5.2 Solar Power Curve	23
5.3 Curve Page-solar& Load & Grid	24

5.4 System Setup Menu	25
5.5 Basic Setup Menu	25
5.6 Battery Setup Menu	25
5.7 System Work Mode Setup Menu	27
5.8 Grid setup Menu	28
5.9 Generator Port use setup Menu	31
5.10 Advanced Function Setup Menu	32
5.11 Device Info setup Menu	33
6. Mode	33
7. Fault information and processing	35
8. Limitation of Liability	38
9. Datasheet	39
10. Appendix I	40
11. Appendix II	42

1. Safety Introductions Safety signs

Symbol	Symbolic Meaning
	The DC input terminals of the inverter must not be grounded.
	Prohibit disassembling inverter case, there existing shock hazard, which may cause serious injury or death, please ask qualified person to repair. High touch current earth connection essential before connecting supply.
	Surface high temperature, Please do not touch the inverter case.
	Please read the instructions carefully before use.
	Do Not put it in the waste bin! Recycle it by licensed professional !
	The AC and DC circuits must be disconnected separately, and the maintenance personnel must wait for 5 minutes before they can start working.

- This chapter contains important safety and operating instructions. Read and keep this manual for future reference.
- Before using the inverter, please read the instructions and warning signs of the battery and corresponding sections in the instruction manual.
- Do not disassemble the inverter, If you need maintenance or repair, take it to a professional service center.
- Improper reassembly may result in electric shock or fire.
- To reduce risk of electric shock, disconnect all wires before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
- Caution: Only qualified personnel can install this device with battery.
- Never charge a frozen battery.
- For optimum operation of this inverter, please follow required specification to select appropriate cable size. It is very important to correctly operate this inverter.
- Be very cautious when working with metal tools on or around batteries. Dropping a tool may cause a spark or short circuit in batteries or other electrical parts, even cause an explosion.
- Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to "installation" section of this manual for the details.


- Grounding instructions – this inverter should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
- Never cause AC output and DC input short circuited. Do not connect to the mains when DC input short circuits.

2. Product Introductions

This is a multifunctional inverter, combining functions of inverter, solar charger and battery charger to offer uninterruptible power support with portable size. Its comprehensive LCD display offers user configurable and easy accessible button operation such as battery charging, AC/solar charging, and acceptable input voltage based on different applications.

2.1 Product Size



DGH02-P1M6K-EU



1. Inverter Indicators 2. LCD Display 3. Function Buttons 4. Box 5. Power on/off button 6. COM1 7. COM2 8. WiFi Interface 9. Bat+ 10. Bat- 11. GRID 12. GEN 13. LOAD 14. PV1 15. PV2

*for some hardware versions, the circuit breaker of Grid is not existed



DGH02-P1M8K-EU



1.Inverter Indicators 2.LCD Display 3.Function Buttons 4.PV switch 5.Box 6.Power on/off button 7.COM1 8.COM2 9.WiFi Interface 10.Bat+ 11.Bat- 12.GRID 13.GEN 14.LOAD 15.PV1 16.PV2

*for some hardware versions, the circuit breaker of Grid is not existed

DGH02-P1M10K-EU DGH02-P1M12K-EU



1.Inverter Indicators 2.LCD Display 3.Function Buttons 4.PV switch 5.Box 6.Power on/off button 7.COM1 8.COM2 9.WiFi Interface 10.Bat+ 11.Bat- 12.GRID 13.GEN 14.LOAD 15.PV1 16.PV2

*for some hardware versions, the circuit breaker of Grid is not existed

2.2 Product Features

- Self-consumption and feed-in to the grid.
- Auto restart while AC is recovering.
- Programmable supply priority for battery or grid.
- Programmable multiple operation modes: On grid,off grid and UPS.
- Configurable battery charging current/voltage based on applications by LCD setting.
- Configurable AC/Solar/Generator Charger priority by LCD setting.
- Compatible with mains voltage or generator power.
- Overload/over temperature/short circuit protection.
- Smart battery charger design for optimized battery performance.
- With limit function, prevent excess power overflow to the grid.
- Supporting WIFI monitoring and build-in 2 strings of MPPT trackers.
- Smart settable three stages MPPT charging for optimized battery performance.
- Time of use function.
- Smart Load Function.

2.3 Basic System Architecture


The following illustration shows basic application of this inverter. It also includes following devices to have a Complete running system.

-Generator or Utility.

-PV modules.

Consult with your system integrator for other possible system architectures depending on your requirements.

This inverter can power all kinds of appliances in home or office environment, including motor type appliances such as refrigerator and air conditioner.



3. Installation

3.1 Parts List

Check the equipment before installation, Please make sure nothing is damaged in the package. You should have received the items in the following package:


	Inverter*1		User manual*1
	Expansion bolt M8*100 *2		Parallel communication cable*1
	Wi-Fi-Plug(optional) *1		Sensor Clamp *1
	Stainless steel mounting screws M6*14x4		

3.2 Mounting instructions Installation Precaution

This inverter is designed for outdoor use(IP65), Please make sure the installation site meets below conditions:


- Not in direct sunlight.
- Not in areas where highly flammable materials are stored.
- Not in potential explosive areas.
- Not in the cool air directly.
- Not near the television Antenna or antenna cable.
- Not higher than altitude of about 2000 meters above sea level.
- Not in environment of precipitation or humidity(>95%).

Please AVOID direct sunlight, rain exposure, snow laying up during installation and operation. Before connecting all wires, please take off the metal cover by removing screws as show below:



Considering the following points before selecting where to install:

- Please select a vertical wall with load-bearing capacity for installation, suitable for installation on concrete or other non-flammable surfaces, installation is shown below.
- Install this inverter at eye level in order to allow the LCD display to be read at all times.
- The ambient temperature is recommended to be between -40~60°C to ensure optimal operation.
- Be sure to keep other objects and surfaces as shown in the diagram to guarantee sufficient heat dissipation and have enough space for removing wires.




For proper air circulation to dissipate heat, allow a clearance of approx. 50cm to the side and approx. 50cm above and below the unit. And 100cm to the front.


Mounting the inverter

Remember that this inverter is heavy! Please be careful when lifting out from the package. Choose the recommend drill head (as shown in below pic) to drill 4 holes on the wall, 72~80mm deep.

1. Use a proper hammer to fit the expansion bolt in to the holes.
2. Carry the inverter and holding it, make sure the hanger aim at the expansion bolt, fix the inverter on the wall.
3. Fasten the screw head of the expansion bolt to finish the mounting.



Inverter hanging plate installation



3.3 Battery connect on


For safe operation and compliance, a separate DC over-current protector or disconnect device is required between the battery and the inverter. In some applications, switching devices may not be required but over-current protectors are still required. Refer to the typical amperage in the table below for the required fuse or circuit breaker size.

Model	Wire Size	Cable(mm ²)	Torque Value(max)
6kW	2AWG	35	24.5Nm
8kW	1AWG	50	24.5Nm
10kW/12kW	0AWG	70	24.5Nm


	Connecting the battery with a suitable cable is important for safe and efficient operation of the system. To reduce the risk of injury, refer to Chart 3-2 for recommended cables.
	All wiring must be performed by a professional person.

Please follow below steps to implement battery connection:

1. Please choose a suitable battery cable with correct connector which can well fit into the battery terminals.
2. Use a suitable screwdriver to unscrew the bolts and fit the battery connectors in. then fasten the bolt by the screwdriver, make sure the bolts are tightened with torque of 5.2 N.M in clockwise direction.
3. Make sure polarity at both the battery and inverter is correctly connected.
4. In case of children touch or insects go into the inverter, Please make sure the inverter connector is fasten to waterproof position by twist it clockwise.




For 6kW~12kW model, battery connector screw size: M10



DC Battery Input

	Installation must be performed with care.
	Before making the final DC connection or closing DC breaker/disconnect, be sure positive(+) must be connect to positive(+) and negative(-) must be connected to negative(-). Reverse polarity connection on battery will damage the inverter.

3.3.2 Function port definition



TEMP(1,2): battery temperature sensor for lead acid battery.

CT(3,4): current transformer for "zero export to CT" mode.

G-start/G-valve(5,6/7,8): dry contact signal for startup the diesel generator.

When the "GEN signal" is active, the open contact (G-start/G-valve) will switch on (no voltage output). If the "signal ISLAND MODE" is ticked, the G-valve port will be the dry contact signal for startup the diesel generator. If "signal ISLAND MODE" is not ticked, the G-start port will be the dry contact signal for startup the diesel generator.


ATS240V: If the conditions are met, it will output 230Vac.

DIP Switch for ATS240V: This DIP Switch (2 set) is used to turn on/off the output voltage of ATS port. When both of them are in "ON" position, then the output voltage of ATS port will be active. When both of them are in "OFF" position, then the output voltage of ATS port will be not active.

RSD short signal/RSD voltage signal(B,B/+,-): when the terminal "B" & "B" is short-circuited with additional wire connection, or there's 12Vdc input at the terminal "+ & -". then the 12Vdc of RSD+ & RSD- will disappear immediately, and the inverter will shutdown immediately.

RSD 12V out(17,18): When battery is connected and the inverter is in "ON" status, it will provide 12Vdc.

DIP Switch for Parallel Function: Parallel communication resistor. If the number of inverters in the parallel system is less than or equal to 6, all inverter's DIP switch (1&2) need be ON position. If the number of inverters in parallel system exceeds 6, the main 6pcs inverter's DIP switch needs to be ON position. And the other inverter DIP switch(1&2) needs to be OFF position.



3.4 Grid connection and backup load connection

Before connecting to the grid, a separate AC breaker must be installed between the inverter and the grid, and also between the backup load and the inverter. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current. For the 6/8KW model, the recommended AC breaker for backup load 6KW is 40A, 8KW is 63A..For the 6/8KW model, the recommended AC breaker for grid 6KW is 40A, 8KW is 63A.

There are three terminal blocks with "Grid" "Load" and "GEN" markings. Please do not misconnect input and output connectors.




All wiring must be performed by a qualified personnel. It is very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable as below.

Model	Wire Size	Cable(mm ²)	Torque Value(max)
6kW	8AWG	8	1.2Nm
8kW	6AWG	13	1.2Nm
10kW/12kW	4AWG	21.1	1.2Nm

Chart 3-3 Recommended Size for AC wires

Please follow below steps to implement AC input/output connection:

- Before making Grid, load and Gen port connection, be sure to turn off AC breaker or disconnect first.
- Remove insulation sleeve 10mm length, unscrew the bolts, insert the wires according to polarities indicated on the terminal block and tighten the terminal screws. Make sure the connection is



Be sure that AC power source is disconnected before attempting to wire it to the unit.

3.5 PV Connection

Model	Wire Size	Cable(mm ²)	PV Current
6/8/10/12kW	10AWG	6	26A

Chart 3-4 Cable size

	To avoid any malfunction, do not connect any PV modules with possible current leakage to the inverter. For example, grounded PV modules will cause current leakage to the inverter. When using PV modules, please ensure the PV+ & PV- of solar panel is not connected to the system ground bar.
	It is requested to use PV junction box with surge protection. Otherwise, it will cause damage on inverter when lightning occurs on PV modules.


3.5.1 PV Module Selection:

- 1) Open circuit Voltage (Voc) of PV modules not exceeds max. PV array open circuit voltage of inverter.
- 2) Open circuit Voltage (Voc) of PV modules should be higher than min. start voltage.
- 3) The PV modules used to connected to this inverter shall be Class A rating certified according to IEC 61730.


Inverter Model	6kW	8kW	10kW/12kW
PV Input Voltage	370V(125V~500V)		
PV Array MPPT Voltage Range	150V~425V		
No. of MPPT Trackers	2	2	3
No. of Strings per MPPT Tracker	1+1	1+1	1+1+1


Chart 3-5

3.6 CT Connection



3.61 Meter Connection






Note:

In final installation, breaker certified according to IEC 60947-1 and IEC 60947-2 shall be installed with the equipment.

3.7 Earth Connection(mandatory)

Ground cable shall be connected to ground plate on grid side this prevents electric shock. if the original protective conductor fails.





Model	Wire Size	Cable(mm ²)	Torque Value(max)
6kW	8AWG	8	1.2Nm
8kW	6AWG	13	1.2Nm
10kW/12kW	4AWG	21.1	1.2Nm

3.8 WIFI Connection


For the configuration of Wi-Fi Plug, please refer to illustrations of the Wi-Fi Plug. The Wi-Fi Plug is not a standard configuration, it's optional.

3.9 Wiring system for inverter




3.10 Typical application diagram of diesel generator


(Region:EU)



3.11 Single phase parallel connection diagram



3.12 Three phase Parallel inverter



A Phase Master Inverter

Advanced Function 2

☒ Parallel
Modbus SN: 01

☒ Master ☐ Slave
☒ A Phase ☐ B Phase ☐ C Phase

☐ Ex_Meter For CT
☐ A Phase ☐ B Phase ☐ C Phase
Meter Select: ☐ No Meter ☐ ATIS ☐ OFF

Exit Save

B Phase Master Inverter

Advanced Function 2

☒ Parallel
Modbus SN: 02

☒ Master ☐ Slave
☐ A Phase ☒ B Phase ☐ C Phase

☐ Ex_Meter For CT
☐ A Phase ☐ B Phase ☐ C Phase
Meter Select: ☐ No Meter ☐ ATIS ☐ OFF

Exit Save

C Phase Master Inverter

Advanced Function 2

☒ Parallel
Modbus SN: 03

☒ Master ☐ Slave
☐ A Phase ☐ B Phase ☒ C Phase

☐ Ex_Meter For CT
☐ A Phase ☐ B Phase ☐ C Phase
Meter Select: ☐ No Meter ☐ ATIS ☐ OFF

Exit Save

4. OPERATION

4.1 Power ON/OFF

Once the unit has been properly installed and the batteries are connected well, simply press On/Off button (located on the left side of the case) to turn on the unit. When system without battery connected, but connect with either PV or grid, and ON/OFF button is switched off LCD will still light up (Display will show OFF), in this condition, when switch on ON/OFF button and select NO battery, system can still working.

4.2 Operation and Display Panel

The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes four indicators, four function keys and a LCD display, indicating the operating status and input/output power information.

LED Indicator		Messages
DC	Green led solid light	PV Connection normal
AC	Green led solid light	Grid Connection normal
Normal	Green led solid light	Inverter operating normal
Alarm	Red led solid light	Malfunction or warning

Chart 4-1 LED indicators


LED Indicator	Description
ESC	To exit setting mode
UP	To go to previous selection
Down	To go to next selection
Enter	To confirm the selection

Chart 4-2 Function Buttons

5. LCD Display Icons

5.1 Main Screen

The LCD is touch screen, below screen shows the overall information of the inverter.



1.The icon in the center of the home screen indicates that the system is Normal operation. If it turns into "comm./F01-F64",it means the inverter has communication errors or other errors,the error message will display under this icon(F01-F64 errors, detail error info can be viewed in the System Alarms menu).


2.At the top of the screen is the time.

3.System Setup Icon, Press this set button,you can enter into the system setup screen which including Basic Setup, Battery Setup, Grid Setup, System Work Mode, Generator port use,Advanced function and Li-Batt info.

4.The main screen showing the info including Solar, Grid, Load and Battery. its also displaying the energy flow direction by arrow. When the power is approximate to high level, the color on the panels will changing from green to red so system info showing vividly on the main screen.

- PV power and Load power always keep positive.
- Grid power negative means sell to grid, positive means get from grid.
- Battery power negative means charge, positive means discharge.

5.1.1 LCD operation flow chart



5.2 Solar Power Curve




This is Solar Panel detail page.

① Solar Panel Generation.

② Solar Panel energy for Day and Total.

③ Voltage, Current, Power for each MPPT. Press the "Energy" button will enter into the power curve page.

*** Note:** this part info is not available for some LCD FW.



This is inverter detail page.

Inverter Generation.

Voltage, Current, Power for each Phase.

*** Note:** this part info is not available for some LCD FW.




This is Backup Load detail page.

① Back-up Power.

② Voltage, Power for each Phase.

③ Back-up consumption for Day and Total. Press the "Energy" button will enter into the powercurve page.

*** Note:** this part info is not available for some LCD FW.



This is Backup Load detail page.

① Status, Power, Frequency.

② L: Voltage for each Phase

CT: Power detected by the external current sensors



LD: Power detected using internal sensors on AC grid in/out breaker

③ **BUY:** Energy from Grid to Inverter,

SELL: Energy from Inverter to grid.

Press the "Energy" button will enter into the powercurve page.

*** Note:** this part info is not available for some LCD FW.







This is Battery detail page.

if you use Lithium Battery, you can enter BMS page.

*** Note:** this part info is not available for some LCD FW.


5.3 Curve Page-solar& Load & Grid



Solar power curve for daily, monthly, yearly and total can be roughly checked on the LCD, for more accuracy power generation, pls check on the monitoring system. Click the up and down arrow to check power curve of different period.


*** Note:** this part info is not available for some LCD FW,

5.4 System Setup Menu



This is System Setup page.


5.5 Basic Setup Menu



Factory Reset: Reset all parameters of the inverter.
Before performing, a successful factory reset and locking the systems, to keep all changes you need to type in a password to enable the setting.

The password for factory settings is 7777.


*** Note:** this part info is not available for some LCD FW.



Factory Reset Password: 7777

*** Note:** this part info is not available for some LCD FW.

5.6 Battery Setup Menu



Battery capacity: it tells us inverter to know your battery bank size.

Use Batt V: Use Battery Voltage for all the settings (V).

Use Batt %: Use Battery SOC for all the settings (%).

Max, A charge/discharge: Max battery charge/discharge current (0-120A for 5kW model, 0-135A for 6kW model, 0-190A for 8kW model).

For AGM and Flooded, we recommend Ah battery size x 20% = Charge/Discharge amps.


. For Lithium, we recommend Ah battery size x 50% = Charge/Discharge amps.

. For Gel, follow manufacturer's instructions.

No Batt: tick this item if no battery is connected to the system.

Active battery: This feature will help recover a battery that is over discharged by slowly charging from the solar array or grid.

*** Note:** this part info is not available for some LCD FW.



This is Battery Setup page. ①③

Start = 30%: Percent S.O.C at 30% system will AutoStart a connected generator to charge the battery bank.

A = 40A: Charge rate of 40A from the attached generator in Amps.

Gen charge: uses the gen input of the system to charge battery bank from an attached generator.

Gen signal: Normally open relay that closes when the Gen Start signal state is active.

Gen Force: When the generator is connected, it is forced to start the generator without meeting other conditions.

Low Noise Mode: in this mode, inverter will work in "low noise mode".

This is Grid charge, you need select. ②


Start = 30%: No use, Just for customization.

A = 40A: It indicates the Current that the Grid charges the Battery.


Grid Charge : It indicates that the grid charges the battery.

Grid Signal: Disable.

*** Note:** this part info is not available for some LCD FW.




This page tells the Pv and diesel generator power the load and battery.




This page tells generator output voltage, frequency, power, And, how much energy is used from generator.

*** Note:** this part info is not available for some LCD FW.



Lithium Mode: This is BMS protocol. Please reference the document (Approved Battery).
Shutdown 10%: It indicates the inverter will shutdown if the SOC below this value.
Low Batt 20%: It indicates the inverter will alarm if the SOC below this value.
Restart 40%: Battery voltage at 40% AC output will resume.
*** Note:** this part info is not available for some LCD FW.
 If battery communication port is CAN pls set "0" or "1" for RS485 in the first column of "Lithium Mode" as below



There are 3 stages of charging the Battery. ①
 This is for professional installers, you can keep it if you do not know.
shutdown 20%: The inverter will shutdown if the SOC below this value.
Low Batt 35%: The inverter will alarm if the SOC below this value. ③
Restart 50%: Battery SOC at 50% AC output will resume.

Recommended battery settings

Battery Type	Absorption Stage	Float Stage	Torque value(every 30 days 3hr)
AGM (or PCC)	14.2V (57.6V)	13.4V (53.6V)	14.2V(57.6V)
Gel	14.1V(56.4V)	13.5V(54.0V)	
Wet	14.7V (59.0V)	13.7V(55.0V)	14.7V (59.0V)
Lithium	Follow its BMS voltage parameters		

5.7 System Work Mode




Work Mode


Selling First: This Mode allows inverter to sell back any excess power produced by the solar panels to the grid. if time of use is active, the battery energy also can be sold into grid.
 The PV energy will be used to power the load and charge the battery and then excess energy will flow to grid.
 Power source priority for the load is as follows:

1. Solar Panels.
2. Grid.
3. Batteries (until programmable 9 discharge is reached).

Zero Export To Load: Inverter will only provide power to the backup load connected. The inverter will neither provide power to the home load nor sell power to grid. The built-in CT will detect power flowing back to the grid and will reduce the power of the inverter only to supply the local load and charge the battery.



Zero Export To CT: inverter will not only provide power to the backup load connected but also give power to the home load connected. If PV power and battery power is insufficient, it will take grid energy as supplement. The inverter will not sell power to grid. In this mode, a CT is needed. The installation method of the CT please refer to chapter 3.6 CT Connection. The external CT will detect power flowing back to the grid and will reduce the power of the inverter only to supply the local load, charge battery and home load.



Solar Sell: "solar sell" is for Zero export to load or Zero export to CT: when this item is active, the surplus energy can be sold back to grid. When it is active, PV Power source priority usage is as follows: load consumption and charge battery and feed into grid.

Max. sell power: Allowed the maximum output power to flow to grid.

Zero-export Power: for zero-export mode, it tells the grid output power, Recommend to set it as 20-100W to ensure the inverter won't feed power to grid.

Energy Pattern: PV Power source priority.

Batt First: PV power is firstly used to charge the battery and then used to power the load. If PV power is insufficient, grid will make supplement for battery and load simultaneously.

Load First: PV power is firstly used to power the load and then used to charge the battery. If PV power is insufficient grid will make supplement for battery and load simultaneously.

Max Solar Power: allowed the maximum DC input power.

Grid Peakshaving: when it is active, grid output power will be limited within the set value. if the load power exceeds the allowed value, it will take PV energy and battery as supplement if still can't meet the load requirement, grid power will increase to meet the load needs.

Time of use: it is used to program when to use grid or generator to charge the battery, and when to discharge the battery to power the load. Only tick "Time Of Use" then the follow items (Grid, charge, time, power etc.) will take effect.

Note: when in selling first mode and click time of use, the battery power can be sold into grid. It allows users to choose which day to execute the setting of "Time of Use".

For example, the inverter will execute the time of use page on Mon/Tue/Wed/Thu/Fri/Sat only.

* **Note:** this part info is not available for some LCD FW.

Grid charge: utilize grid to charge the battery in a time period.

Gen charge: utilize diesel generator to charge the battery in a time period.

Time: real time, range of 01:00-24:00.

Power: Max. discharge power of battery allowed. action is to happen.

Batt(V or SOC %): battery SOC % or voltage at when the action is to happen.

For example: During 01:00-05:00, when battery SOC is lower than 80%, it will use grid to charge the battery until battery SOC reaches 80%.

During 05:00-08:00 and 08:00-10:00, when battery soc is higher than 40%, inverter will discharge the battery until the SOC reaches 40%.

During 10:00-15:00, when battery soc is higher than 80%, inverter will discharge the battery until the SOC reaches 80%.

During 15:00-18:00, when battery soc is higher

than 40% inverter will discharge the battery until the SOC reaches 40%.

During 18:00-01:00, when battery soc is higher than 35%, inverter will discharge the battery until the SOC reaches 35%.

* **Note:** this part info is not available for some LCD FW.

5.8 Grid setup Menu

Grid Mode:

General Standard, UL1741 & IEEE1547, CPUC RILE21, SRD-UL-1741, CEIO-21, EN50549 CZ, Australia A, Australia B, Australia C, New Zealand, VDE4105, OVE_Directive R25, EN50549_CZ, PPDS L16A, NRS097, G98/G99, G98/G99 NI, ESB Networks(Ireland). Please follow the local grid code and then choose the corresponding grid standard.

This is Grid Warning page.

Normal connect: The allowed grid voltage/frequency range when the inverter first time connect to the grid.

Normal Ramp rate: It is the startup power ramp.

Reconnect after trip: The allowed grid voltage/frequency range for the inverter connects the grid after the inverter trip from the grid.

Reconnect Ramp rate: It is the reconnection power ramp.

Reconnection time: The waiting time period for the inverter connects the grid again.

PF: Power factor which is used to adjust inverter reactive power.

HV1: Level 1 overvoltage protection point;
① HV2: Level 2 overvoltage protection point; ② 0.10s- Trip time.
HV3: Level 3 overvoltage protection point.
LV1: Level 1 undervoltage protection point;
LV2: Level 2 undervoltage protection point;
LV3: Level 3 undervoltage protection point.
HF1: Level 1 over frequency protection point;
HF2: Level 2 over frequency protection point;
HF3: Level 3 over frequency protection point.
LF1: Level 1 under frequency protection point;
LF2: Level 2 under frequency protection point;
LF3: Level 3 under frequency protection point.

5.9 Generator Portuse setup Menu

Generator input rated power: allowed Max. power from diesel generator.

GEN connect to grid input: connect the diesel generator to the grid input port.

Smart Load Output: This mode utilizes the Gen input connection as an output which only receives power when the battery SOC and PV power is above a user programmable threshold. e.g. Power=500W, ON: 100%, OFF=95%:

When the PV power exceeds 500W, and battery bank SOC reaches 100%, Smart Load Port will switch on automatically and power the load connected. When the battery bank SOC < 95% or PV power < 500W, the Smart Load Port will switch off automatically.

Smart Load OFF Batt

· Battery SOC at which the Smart load will switch off.

Smart Load ON Batt

· Battery SOC at which the smart load will switch on. Also, the PV input power should exceed the setting value (Power) simultaneously and then the Smart load will switch on.

On Grid always on: When click "on Grid always on" the smart load will switch on when the grid is present.

Micro Inv input: To use the Generator input port as a micro-inverter on grid inverter input (Ac coupled), this feature will also work with "Grid-Tied" inverters.

*** Micro iny input OFF:** when the battery SOC exceeds setting value, Microinverter or grid-tied inverter will shut down.

*** Micro Iny input ON:** when the battery SOC is lower than setting value, Microinverter or grid-tied inverter will start to work.

AC Couple Fre High: If choosing "Micro Inv input", as the battery SOC reaches gradually setting value (OFF), During the process, the microinverter output power will decrease linear, When the battery SOC equals to the setting value (OFF), the system frequency will become the setting value (Ac couple Fre high) and the Microinverter will stop working.

Stop exporting power produced by the microinverter to the grid.


*** Note:** Micro Inv Input OFF and On is valid for some certain FW version only.

*** AC couple on load side:** connecting the output of on-grid inverter at the load port of the inverter. in this situation, the hybrid inverter will not able to show the load power correctly,

*** AC couple on grid side:** this function is reserved.

*** Note:** Some firmware versions don't have this function.

5.10 Advanced Function Setup Menu



Solar Arc Fault ON: This is only for Us.

System selfcheck: Disable. this is only for factory.

Gen Peak-shaving: Enable When the power of the generator exceeds the rated value of it, the inverter will provide the redundant part to ensure that the generator will not overload.

DRM: For AS4777 standard

Backup Delay: (0-300)S adjustable

BMS Err Stop: When it is active, if the battery BMS failed to communicate with inverter, the inverter will stop working and report fault.

Signal ISLAND MODE: when "signal island mode" is checked and the inverter connects the grid, the ATS port voltage will be 0. When "signal island mode" is checked and the inverter disconnected from the grid, the ATS port voltage will output 230Vac voltage. With this feature and outside No type relay, it can realize N and PE disconnection or bond.



More details, please refer to left side picture.

*** Note:** this part info is not available for some LCD FW.

Ex Meter For CT: when in Three phase system with CHINT Three phase energy meter (DTSU666), click corresponding phase where inverter is connected. e.g. when the inverter output connects to A phase, please click A Phase.

Meter Select: select the corresponding meter type according to the meter installed in the system.

Note: this part info is not available for some LCD FW.



5.11 DeviceInfo setup Menu


DeviceInfo

Dev.Type : Single-phase 8KW
Dev.SN : DN2408027217
Lcd Ver : V1.0.3
Ctrl Ver : V1.1.0


This page show Inverter ID, inverter version and alarm codes.
HMI: LCD version
*** Note:** this part info is not available for some LCD FW.

6. Mode


Mode I:Basic






Mode II: with Generator



Mode III: With Smart-Load



Mode IV: AC Couple





The 1st priority power of the system is always the PV power, then 2nd and 3rd priority power will be the battery bank or grid according to the settings. The last power backup will be the Generator if it is available.

7. Fault information and processing

The energy storage inverter is designed according to the grid-connected operation standard and meets the safety requirements and electromagnetic compatibility requirements. Before leaving the factory, the inverter undergoes several rigorous tests to ensure that the inverter can operate reliably.



If any of the fault messages listed in Table 7-1 appear on your inverter and the fault has not been removed after restarting, please contact your local dealer or service center. You need to have the following information ready.

1. Inverter serial number;
2. Distributor or service center of the inverter ;
3. On-grid power generation date;
4. The problem description (including the fault code and indicator status displayed on the LCD) is as detailed as possible.
5. Your contact information, in order to give you a clearer understanding of the inverter's fault information, we will list all possible fault codes and their descriptions when the inverter is not working properly.

Error code	Description	Solutions
F08	GFDI _Relay_Failure	1. When inverter is in Split phase(120/240Vac) or three-phase system(120/208Vac) system, the backup load port N line needs to connect ground; 2. If the fault still exists, please contact us for help.
F13	Working mode change	1. When the grid type and frequency changed it will report F13; 2. When the battery mode was changed to "No battery" mode, it will report F13; 3. For some old FW version, it will report F13 when the system work mode changed; 4. Generally, it will disappear automatically when shows F13; 5. If still same, and turn off the DC switch and AC switch and wait for one minute and then turn on the DC/AC switch; 6. Seek help from us, if can not go back to normal state.

F18	AC over current fault of hardware	AC side over current fault 1. Please check whether the backup load power and common load power are within the range; 2. Restart and check whether it is in normal; 3. Seek help from us, if can not go back to normal state.
F20	DC over current fault of the hardware	DC side over current fault 1. Check PV module connect and battery connect; 2. When in the off-grid mode, the inverter startup with big power load, it may report F20, Please reduce the load power connected; 3. Turn off the DC switch and AC switch and then wait one minute, then turn on the DC/AC switch again; 4. Seek help from us, if can not go back to normal state.
F22	Tz_EmergStop_Fault	Please contact your installer for help.
F23	AC leakage current is transient over current	Leakage current fault 1. Check PV side cable ground connection. 2. Restart the system 2~3 times. 3. If the fault still exists, please contact us for help
F24	DC insulation impedance failure	PV isolation resistance is too low 1. Check the connection of PV panels and inverter is firmly and correctly; 2. Check whether the PE cable of inverter is connected to ground; 3. Seek help from us, if can not go back to normal state.
F26	The DC busbar is unbalanced	1. Please wait for a while and check whether it is normal; 2. When in the split phase mode, and the load of L1 and load of L2 is big different, it will report the F26. 3. Restart the system 2~3 times. 4. Seek help from us, if can not go back to normal state.
F29	Parallel CANBus fault	1. When in parallel mode, check the parallel communication cable connection and inverter communication address setting; 2. During the parallel system startup period, inverters will report F29 when all inverters are in ON status, it will disappear automatically; if the fault still exists, please contact us for help.

Error code	Description	Solutions
F34	AC Overcurrent fault	1.Check the backup load connected, make sure it is in allowed power range; 2.If the fault still exists,please contact us for help.
F35	No AC grid	1.No Utility 2.Please confirm grid is lost or not; 3.Check the grid connection is good or not; 4.Check the switch between inverter and grid is on or not; 5.Seek help from us, if can not go back to normal state.
F41	Parallel system stop	1.Check the hybrid inverter working status, if there's 1 pcs hybrid inverter is in OFF status, the other hybrid inverters may report F41 fault in parallel system. 2.If the fault still exists, please contact us for help.
F42	AC line low voltage	Grid voltage fault 1.Check the AC voltage is in the range of standard voltage in specification; 2.Check whether grid AC cables are firmly and correctly connected; 3.Seek help from us, if can not go back to normal state.
F47	AC over frequency	Grid frequency out of range 1.Check the frequency is in the range of specification or not, 2.Check whether AC cables are firmly and correctly connected; 3.Seek help from us, if can not go back to normal state.
F48	AC lower frequency	Grid frequency out of range 1.Check the frequency is in the range of specification or not; 2.Check whether AC cables are firmly and correctly connected; 3.Seek help from us, if can not go back to normal state.
F56	DC busbar voltage is too low	Battery voltage low 1.Check whether battery voltage is too low; 2.If the battery voltage is too low, using PV or grid to charge the battery; 3.Seek help from us, if can not go back to normal state.
F58	BMS communication fault	1.it tells the communication between hybrid inverter and battery BMS disconnected when"BMS_Err-Stop" is active; 2.if don't want to see this happen, you can disable "BMS_Err-Stop" item on the LCD; 3.If the fault still exists, please contact us for help.
F63	ARC fault	1.ARC fault detection is onlyfor US market; 2.Check PV module cable connection and clear the fault; 3.Seek help from us, if can not go back to normal state.

F64	Heat sink high temperature failure	Heat sink temperature is too high 1.Check whether the work environment temperature is too high; 2.Turn off the inverter for 10mins and restart; 3.Seek help from us, if can not go back to normal state.
-----	------------------------------------	---

Under the guidance of our company, customers return our products so that our company can provide service of maintenance or replacement of products of the same value. Customers need to pay the necessary freight and other related costs. Any replacement or repair of the product will cover the remaining warranty period of the product. If any part of the product or product is replaced by the company itself during the warranty period, all rights and interests of the replacement product or component belong to the company.

Factory warranty does not include damage due to the following reasons:

- Damage during transportation of equipment;
- Damage caused by incorrect installation or commissioning;
- Damage caused by failure to comply with operation instructions, installation instructions or maintenance instructions;
- Damage caused by attempts to modify, alter or repair products;
- Damage caused by incorrect use or operation;
- Damage caused by insufficient ventilation of equipment;
- Damage caused by failure to comply with applicable safety standards or regulations;
- Damage caused by natural disasters or force majeure (e.g. floods, lightning, overvoltage, storms, fires, etc.)

In addition, normal wear or any other failure will not affect the basic operation of the product. Any external scratches, stains or natural mechanical wear does not represent a defect in the product.

8. Limitation of Liability

In addition to the product warranty described above, the state and local laws and regulations provide financial compensation for the product's power connection (including violation of implied terms and warranties). The company hereby declares that the terms and conditions of the product and the policy cannot and can only legally exclude all liability within a limited scope.

9. Datasheet



Model	6K	8K	10K	12K
Battery Input Data				
Battery Type	Lead-acid or Li-ion			
Battery Voltage Range(V)	40-60			
Max. Charging Current(A)	135	190	220	250
Max. Discharging Current(A)	135	190	220	250
External Temperature Sensor	yes			
PV String Input Data				
Max DC input Power(W)	9000	12000	13000	15600
PV Input Voltage(V)	370V (125V-500V)			
MPPT Range(V)	150-425V			
Full Load DC Voltage Range	300-425V			
Start-up Voltage(V)	125V			
PV input Current(A)	18+18	26+26	26+26+26	26+26+26
Max.PV Isc(A)	27+27	34+34	34+34+34	34+34+34
No. of MPPT Trackers	2	2	3	3
Number of Strings per MPPT Tracker	1+1	1+1	1+1+1	1+1+1
AC Input/output Data				
Rated AC Output and UPS Power(W)	6000	8000	10000	12000
Max. AC Output Power(VA)	6600	8800	11000	13200
Peak Power(off grid)	Double rated Power,10S			
AC Input/output Rated Current(A)	27.3/26.1	36.4/34.8	45.5/43.5	54.6/52.2
Max. AC input/Output Current(A)	30/28.7	40/38.3	50/47.9	60/57.4
Max. Continuous AC Passthrough(A)	40	50	60	70
Power Factor	0.8 leading to 0.8 lagging			
Output Frequency and Voltage	50/60Hz; 220/230Vac		100/200Vac;110/220Vac 115/230Vac;120/240Vac	
Grid Type	Single Phase			
Total Harmonic Distortion (THD)	<3% (of nominal power)			
DC Current injection	<0.5% In			
Efficiency				
Max. Efficiency	97.60%			
Euro Efficiency	96.50%			
MPPT Efficiency	>99%			
Protection				
PV Arc Fault Detection	Integrated			
PV input Lightning Protection	Integrated			
Anti-islanding Protection	Integrated			
PV String input Reverse Polarity Protection	Integrated			
Insulation Resistor Detection	Integrated			
Residual Current Monitoring Unit	Integrated			
Output Over Current Protection	Integrated			
Output Shorted Protection	Integrated			
Surge Protection	DC Type II /Ac Type II			
Over Voltage Category	Dc Type II /Ac Type III			

Certifications and Standards			
Grid Regulation	IEC62116,IEC61727		
EMC/Safety Regulation	EN61000-6-2/-4;EN62109-1,EN62109-2		
General Data			
Operating Temperature Range(°C)	-40~60°C,>55°C Derating		
Cooling	Smart cooling		
Noise(dB)	<50 dB		
Communication with BMS	RS485; CAN		
Monitoring mode	Wi-Fi+APP		
Protection Degree	IP65		
Installation Style	Wall-mounted		
Warranty	5 Years (10 Years Optional)		
Weight(kg)	22	25.5	36
Gross weight(kg)	26	29	39
Cabinet size(mm)(LxWxH)			
(Excluding connectors and brackets)	490x340x288	560x340x288	630x430x288
Packing parameters			
Outer box dimensions	680x440x340(mm)		760x530x340(mm)
Pallet dimensions	900x700x120(mm)		1100x800x120(mm)
Pallet 20GP	6 layers:240pcs;7160kg		6 layers:168pcs;6860kg
Pallet 40GP	6 layers:516pcs;15394kg		6 layers:360pcs;14700kg
Pallet 40HQ	7 layers:602pcs;17888kg		7 layers:420pcs;17100kg
Without pallet 20GP	6 layers:301pcs;8729kg		6 layers:238pcs;9520kg
Without pallet 40GP	6 layers:623pcs;18067kg		6 layers:483pcs;19320kg
Without pallet 40HQ	7 layers:623pcs;18067kg		7 layers:483pcs;19320kg


10. Appendix I

Definition of RJ45 Port Pin for BMS 485/CAN.

No	BMS 485/CAN Pin
1	485_B
2	485_A
3	GND_485
4	CAN_H
5	CAN_L
6	GND_485
7	485_A
8	485_B





BMS 485/CAN Port




Definition of RJ45 Port Pin for Rs 485.
This port is used to communicate with energy meter.

No	RS 485 Pin
1	--
2	--
3	--
4	485_B
5	485_A
6	--
7	--
8	--




RS 485 Port



RS 485

No	Pin Name	Pin Type	Description	TyP·
1	VCC	Power	Power	DC 4.8V-5.2V
2	D-	Digital Differential	RS-485 B	-
3	D+	Digital Differential	RS-485 A	-
4	GND	GND	GND	DC 0V



WIFI/RS 485

This RS485 port is used to connect the wifi datalogger

11. Appendix II

1. Split Core Current Transformer(CT)dimension: (mm)
2. Secondary output cable length is 4m.

